

## Rugged crash cart adapter

NOTECONS02X

DE: Bedienungsanleitung - [de.startech.com](https://de.startech.com)  
FR: Guide de l'utilisateur - [fr.startech.com](https://fr.startech.com)  
ES: Guía del usuario - [es.startech.com](https://es.startech.com)  
IT: Guida per l'uso - [it.startech.com](https://it.startech.com)  
NL: Gebruiksaanwijzing - [nl.startech.com](https://nl.startech.com)  
PT: Guia do usuário - [pt.startech.com](https://pt.startech.com)

## Packaging contents

- 1 x rugged crash cart adapter
- 1 x USB A to mini-B cable

## System requirements

### Notebook requirements

- USB 2.0-enabled notebook computer
- 20 MB of available hard drive space
- 24-bit capable display
- One of the following operating systems:
  - Windows® XP, Vista, 7, 8, 8.1, 10, 11
  - Windows Server® 2008 R2, 2012, 2012 R2, 2016, 2019, 2022
  - macOS 10.9 to 10.15, 11.0, 12.0, 13.0, 14.0, 15.0
  - Linux 2.6 to and up - LTS Versions only; glibc 2.18 or newer required

### Server requirements

- VGA-enabled video card (DVI support via optional DVIVGAMF adapter)
- USB keyboard and mouse support

Operating system requirements are subject to change. For the latest requirements, please visit [www.startech.com/NOTECONS02X](https://www.startech.com/NOTECONS02X).

## Product overview



\*actual product may vary from photos



## About the rugged crash cart adapter

You must install the provided software on the laptop to be able to use the crash cart adapter. You don't need to make any changes to the server(s) being controlled, and the crash cart adapter can be connected or disconnected at any time. You don't need to start or shut down the software before you unplug the crash cart adapter.

## Install the software

### Windows

Drivers and software must be installed on the computer before you connect the USB Crash Adapter. To install the software, complete the following:

1. Download the latest drivers from the StarTech.com website, (<https://www.startech.com/NOTECONS02X>).  
**Note:** Windows typically saves the files to the Downloads folder that is associated with your user account (for example, C:\Users\your\_name\Downloads)
2. When the download is complete, right-click the zip folder that you downloaded, click Extract All, and follow the on-screen instructions.
3. In the list of extracted files, navigate to the Windows folder, right-click the Setup.exe file and click Run as Administrator  
**Note:** If the Run as Administrator option is not available, you might be attempting to run the installer from within the zipped file. Extract the files using the instructions in step 2.
4. Follow the on-screen prompts to install the device drivers and software.



## macOS

Drivers and software must be installed on the computer before you connect the USB Crash Adapter. To install the software, complete the following:

1. Download the latest drivers from the StarTech.com website, (<https://www.startech.com/NOTECONS02X>).

**Note:** Mac OS X will typically save the files to the Downloads folder that is associated with your user account (for example, hard\_drive\_name\Users\your\_name\Downloads).

2. Double-click the Software Pack.zip file.
3. Double-click the Install.dmg file.
4. Double-click USB Crash Cart Adapter
5. The program is now located on the desktop and is ready to run.



## FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit than the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device. If shielded interface cables are included with the product, or if additional components or accessories are designated for use with the installation, they must be used to ensure compliance with FCC regulations.

## ISED Statement / Déclaration d'ISDE

T CAN ICES-003(B) / NMB-003(B)

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

## Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit [www.startech.com/support](http://www.startech.com/support) and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit [www.startech.com/downloads](http://www.startech.com/downloads)

## Warranty Information

This product is backed by a two-year warranty.

StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

## Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

## Connect the crash card adapter

After you install the drivers and software for the crash card adapter onto the notebook computer, you can plug the adapter into the server.

- Connect the attached VGA cable and the USB type A to mini-B cable into the desired server. For DVI-I (analog) computer systems, use a DVI to VGA adapter (for example, StarTech.com ID: DVIVGAMF).